



**testo 6321 · differential pressure transmitter
P2A software · Parameterizing, adjusting
and analyzing software**

Instruction manual



1 Safety and the environment

Avoiding electrical hazards

- > Never use the instrument and connected probes to measure on or near live parts!
- > Damaged mains cables must only be replaced by authorized personnel.
- > Only have the transmitter wired and connected by authorized personnel with the voltage disconnected.
- > You must always comply with the regulations applicable in your country for opening and repairing electrical equipment.

Avoiding personal injury and damage to equipment

- > Installation, setting and calibration work must only be carried out by qualified and authorized personnel!
- > Only open the instrument when this is expressly described in the instruction manual for installation, maintenance or repair purposes.
- > Observe the permissible storage, transport and operating temperature.
- > Do not store the product together with solvents. Do not use any desiccants.
- > Do not use the instrument for control purposes at the same time as operating or servicing the transmitter.
- > Only operate the product properly, for its intended purpose and within the parameters specified in the technical data. Do not use any force.
- > Carry out only the maintenance and repair work on this instrument that is described in the documentation. Follow the prescribed steps exactly. Use only original spare parts from Testo.

Any additional work must only be carried out by authorized personnel. Otherwise testo will not accept any responsibility for the proper functioning of the instrument after repair and for the validity of certifications.

Protecting the environment

- > At the end of its useful life, send the product to the separate collection for electric and electronic devices (observe local regulations) or return the product to Testo for disposal.

2 About this document

Use

- > Please read this documentation through carefully and familiarize yourself with the product before putting it to use. Pay particular attention to the safety instructions and warning advice in order to prevent injuries and damage to the products.
- > Keep this document to hand so that you can refer to it when necessary.
- > Hand this documentation on to any subsequent users of the product.

 WARNING	Indicates potential serious injuries
 CAUTION	indicates potential minor injuries

Symbols and writing standards

Representa- tion	Explanation
i	Note: Basic or further information.
1. ... 2. ...	Action: more steps, the sequence must be followed.
> ...	Action: a step or an optional step.
- ...	Result of an action.
Menu	Elements of the program interface.
[OK]	Buttons of the program interface.
... ...	Functions/paths within a menu.
"..."	Example entries

3 Contents

1	Safety and the environment	3
2	About this document.....	4
3	Contents	5
4	Transmitter	7
4.1.	Specifications	7
4.1.1.	Functions and use.....	7
4.1.2.	Scope of delivery	7
4.1.3.	Dimensions	7
4.1.4.	Technical data	8
4.2.	Product description.....	11
4.2.1.	At a glance.....	11
4.2.2.	Scaling.....	12
4.3.	Commissioning	13
4.3.1.	Assembling the instrument.....	13
4.3.1.1.	Wall mounting.....	13
4.3.2.	Wiring the instrument	14
4.3.2.1.	4-wire system	16
4.3.2.2.	3-wire system	16
4.4.	Maintenance and cleaning.....	17
4.4.1.	Cleaning housing	17
4.4.2.	Namur fault conditions	17
5	Parameterizing, adjusting and analyzing software (P2A software).....	18
5.1.	Specifications	18
5.1.1.	Functions and use.....	18
5.1.2.	System requirements	19

3 Contents

5.2.	First steps	20
5.2.1.	Installing the software/driver	20
5.2.1.1.	Installing P2A software.....	20
5.2.1.2.	Installing USB driver.....	20
5.2.1.3.	P2A software upgrade.....	20
5.2.2.	Starting the software.....	21
5.2.2.1.	Starting the program.....	21
5.2.2.2.	Establishing a connection with the instrument	21
5.2.2.3.	Activating the connection with the instrument	21
5.3.	Using the software	22
5.3.1.	User interface	22
5.3.2.	Editing instrument/parameter file.....	24
5.3.2.1.	Changing instrument/parameter file	24
5.3.2.2.	Creating a new instrument file	26
5.3.2.3.	Saving parameters	26
5.3.2.4.	Opening the parameter file	27
5.3.2.5.	Copying and pasting parameters	27
5.3.2.6.	Deleting instrument/parameter file	27
5.3.3.	Analyzing/testing the transmitter	28
5.3.3.1.	Analyzing/testing the instrument.....	28
5.3.3.2.	Carrying out factory reset	28
5.3.3.3.	Testing analog output.....	29
5.3.3.4.	Displaying min./max. values	30
5.3.4.	Adjusting the transmitter	32
5.3.4.1.	n-point adjustment.....	32
5.3.4.2.	Adjusting the analog output	33
5.3.5.	Transmitter history	35
6	Tips and assistance	37
6.1.	Questions and answers	37
6.2.	Accessories and spare parts.....	37
6.2.1.	Ordering options for testo 6321 transmitter (0555 6321)	38

4 Transmitter

4.1. Specifications

4.1.1. Functions and use

The testo 6321 transmitter is suitable for the following applications, amongst others:


- Air conditioning and ventilation technology
 - Monitoring ventilation and filtration systems
 - Monitoring fans
 - Monitoring exhaust air volumetric flow rates

4.1.2. Scope of delivery

The scope of delivery of the testo 6321 transmitter includes the following:

- Assembly accessories
- Operating instructions
- Calibration report

4.1.3. Dimensions



4.1.4. Technical data

Parameter

- Differential pressure

Accuracy¹

The specifications are only valid if the positive pressure is applied at the positive pressure connection.

- 1.2 % of measuring range, additional ± 0.3 Pa intrinsic error ²
- T_K slope drift = 0.05 % of measuring range per degree Kelvin of deviation from nominal temperature 22 °C
- T_K zeroing drift = 0 % (by means of automatic zeroing)

Measuring range, resolution and overload

Measuring range depending on version ordered	Resolution	Overload
0 to 100 Pa	0.1 Pa	20,000 Pa
0 to 10 hPa	0.01 hPa	200 hPa
0 to 20 hPa	0.01 hPa	200 hPa
0 to 50 hPa	0.01 hPa	750 hPa
0 to 100 hPa	0.1 hPa	750 hPa
0 to 500 hPa	0.1 hPa	2500 hPa
0 to 1000 hPa	1 hPa	2500 hPa
0 to 2000 hPa	1 hPa	2500 hPa

¹ At 25 °C. A stabilization period of approx. 30 min must be taken into account upon commissioning the instrument.

² Measuring uncertainty in accordance with GUM: ± 1.2 % of measuring range final value ± 0.3 Pa.

GUM (Guide to the Expression of Uncertainty in Measurement): ISO guideline for determining the measuring uncertainty in order to render global measurement results comparable.

The following uncertainties are used during the inquiry:

- Hysteresis
- Linearity
- Reproducibility
- Long-term stability
- Adjustment area/factory calibration
- Test location

Measuring range depending on version ordered	Resolution	Overload
-100 to 100 Pa	0.1 Pa	20,000 Pa
-10 to 10 hPa	0.01 hPa	200 hPa
-20 to 20 hPa	0.01 hPa	200 hPa
-50 to 50 hPa	0.01 hPa	750 hPa
-100 to 100 hPa	0.1 hPa	750 hPa
-500 to 500 hPa	0.1 hPa	2500 hPa
-1000 to 1000 hPa	1 hPa	2500 hPa
-2000 to 2000 hPa	1 hPa	2500 hPa



Upon delivery and following a factory reset the readings are shown in the display in the unit that was ordered via the KMAT option Fxx, see Ordering options for testo 6321 transmitter (0555 6321) page 38.

Meas. cycle

- 1/sec

Zeroing cycle

- Set to 1 min at the factory

Interface


- Mini-DIN for P2A software (adjustment and parameterization software)

Voltage supply

- 3 or 4-wire (separate signal and supply lines): 20 to 30 V AC/DC, 300 mA power consumption

Maximum load

- 4-wire: 500 Ω (power output)



Maximal load

- 10 k Ω (voltage output)

Analog output

- 0 to 1 V $\pm$ 2.5 mV (4-wire) or
- 0 to 5 V $\pm$ 12.5 mV (4-wire) or
- 0 to 10 V $\pm$ 25 mV (4-wire) or
- 4 to 20 mA $\pm$ 0.05 mA (4-wire)
- $T_K = 0.05$ %K of measuring range per degree Kelvin of deviation from nominal temperature 22 $^{\circ}$ C

Resolution of analog output

- 12 bit

Display

- 2-line LCD (optional)

Operating temperature

- -5 to 50 $^{\circ}$ C

Storage temperature

- -20 to 60 °C

Application humidity

- 0 to 90 % RH

Housing, weight

- Plastic, approx. 160 g

Protection class


- IP 65 only if the transmitter is wired and/or sealing plugs are inserted

Directives, standards and tests

- EC Directive: 2014/30/EC

4.2. Product description

4.2.1. At a glance



4.2.2. Scaling

There are three types of min./max. values:

- 1 The measuring range: The maximum sensor performance is in this range. Measuring range, see table (below).
- 2 Standard scaling: The output signals are assigned to this measuring range as standard:
 - during delivery if no entries are made in the order code
 - after exchanging the unit, the measuring range recorded in the instrument is applied as standard.



The transmitter even retains its scaling with the voltage disconnected.

Measuring range, see table (below).

- 3 The maximum settings for the manual scaling
 - The maximum limits can be calculated as follows:
 $X = \text{difference between MIN. and MAX. value of the standard scaling}$
 $(\text{Max. value of standard}) + (50 \% \text{ of } X)$
 $(\text{Min. value of standard}) - (50 \% \text{ of } X)$
 - It is thus possible to scale beyond the measuring range, e.g. for the adjustment of the scaling limits to standard values of a PLC.

With the alarm definition, however, the physical measuring range limits are decisive.

Measuring range/ standard scaling	Maximum scaling
0 to 100 Pa	-50 to 150
0 to 10 hPa	-5 to 15
0 to 20 hPa	-10 to 30
0 to 50 hPa	-25 to 75
0 to 100 hPa	-50 to 150
0 to 500 hPa	-250 to 750
0 to 1000 hPa	-500 to 1500
0 to 2000 hPa	-1000 to 3000
-100 to 100 Pa	-200 to 200
-10 to 10 hPa	-20 to 20


Measuring range/ standard scaling	Maximum scaling
-20 to 20 hPa	-30 to 30
-50 to 50 hPa	-100 to 100
-100 to 100 hPa	-200 to 200
-500 to 500 hPa	-1000 to 1000
-1000 to 1000 hPa	-2000 to 2000
-2000 to 2000 hPa	-4000 to 4000

4.3. Commissioning

4.3.1. Assembling the instrument

4.3.1.1. Wall mounting


Attaching rear panel bracket



1. Remove locking screw (see item (4) of drawing below) and detach rear panel bracket from plastic bracket (see item (2) of drawing below).
2. Hold rear panel bracket in assembly position and mark the three drill holes.
3. Drill three holes ($\varnothing 5$ mm) and insert dowels where necessary.
4. Screw on rear panel bracket.

Remember that the clamping brackets (1) must face the wall.

Fastening instrument to rear panel bracket



1. Slide plastic bracket (2) on the back of instrument onto rear panel bracket until it engages (see arrows).
2. Insert screw (4) through hole (3) and screw into rear panel bracket.

4.3.2. Wiring the instrument

⚠ WARNING
Electrical voltage!
> When routing cables, ensure that there is a space between the signal line and the interfering external lines. > If electromagnetic interference is likely, use a shielded and/or twisted cable. Connect the shield to the earth on the side facing away from the transmitter. > If overvoltages are likely, install overvoltage protection devices.


⚠ WARNING
Electrical voltage
Danger of injury!
> De-energize the mains connection before connecting the transmitter.

CAUTION**Damage to electronic components!**

- > The terminal strip can be removed from the circuit board in order to screw on the cable ends. After wiring, be sure to completely attach the terminal strip on the contact pins as pre-assembled.




Only have the transmitter wired and connected by authorized personnel with the voltage disconnected.



1. Loosen and remove housing screws (1).
2. Remove upper part of housing (2) from lower part of housing (3) and place on a clean surface.
3. Wire instrument (see 3-wire system page 16, 4-wire system page 16).
4. Place upper part of housing (2) on lower part of housing (3) and tighten with housing screws (1).
5. On instruments with display: Remove protective film (4) from the display cutout of the housing cover.

4.3.2.1. 4-wire system




Voltage output (4-wire, 0 to 1 V/0 to 5 V/0 to 10 V)/voltage output
(4-wire, 4 to 20 mA):

$U = 20$ to 30 V DC/AC

4.3.2.2. 3-wire system

All ground connections are connected to one another (= one collective ground connection).

CAUTION	
Destruction of the instrument in the event of incorrect polarity!	
> When connecting the voltage supply, place collective ground connection on PIN 2!	



4.4. Maintenance and cleaning

4.4.1. Cleaning housing

- Only clean the housing carefully with a moist cloth.
- Do not use aggressive cleaning agents.
- Do not use any solvents.

4.4.2. Namur fault conditions

If the faults named in the following table occur, the analog outputs output special values that enable a general fault warning in the higher-level control system. The values correspond to the "Namur" industry standard.

Status message in the display	Class	Display value in the display	Analog output			
			4 to 20 mA	1 V	5 V	10 V
Watchdog error	Error	Previous value stops	3.8 mA	1.1 V	5.5 V	11 V
Value below min. scale	Underrange	Reading	3.8 mA	0 V	0 V	0 V
Value above max. scale	Overrange	Reading	20.5 mA	1.1 V	5.5 V	11 V
Pressure too high	Overrange	00000	20.5 mA	1.1 V	5.5 V	11 V

5 Parameterizing, adjusting and analyzing software (P2A software)

5.1. Specifications

The P2A software is used for the parameterization, adjustment and analysis of Testo transmitters. The following applies:

- If a Testo transmitter is bought at a later stage (and is therefore more recent than the existing P2A software version), a software update is required.

The software therefore only needs to be bought once, even for owners of several Testo transmitters.

5.1.1. Functions and use

In the P2A software, two different file types are used: The instrument and the parameter file.

Instrument file

The parameters of a particular transmitter are stored in its so-called instrument file. Using this file, the parameters can be edited and the instrument can be tested and adjusted.

Instrument files also contain the respective histories in addition to the parameter data, i.e. "log books" are kept for the previous parameterizations, adjustments and messages (see 5.4.5 Transmitter history).



Instrument files are ".cfm" format files.

Parameter file

Parameter files are not tied to a specific individual transmitter and contain only parameter data/no history data.

If you use various instruments of the same type, you can create parameter files once (e.g. by saving the appropriate instrument file as the parameter file) and transmit these onto the other instruments.



Parameter files are ".cfp" format files.

5.1.2. System requirements

Operating system

- Windows® 7
- Windows® 8
- Windows® 10

Computer

The computer must meet the requirements of the respective operating system. In addition, the following requirements must be met:

- Interface USB 1.1 or higher
- Graphics resolution min. 1024 x 768



Date and time settings are automatically transferred from the PC. The administrator must ensure that the system time is regularly synchronized with a reliable time source and, if necessary, adjusted to ensure the authenticity of the data.

5.2. First steps

5.2.1. Installing the software/driver



Administrator rights are required.

5.2.1.1. Installing P2A software



Without the input of a licence key, the software will run only as a demo version (time limit 30 days).

1. You can download the software
If the installation program does not start automatically:
> Open download folder and start P2A.exe.
2. Follow the instructions of the installation wizard.
3. Click on **[Finish]** to complete the software installation

5.2.1.2. Installing USB driver

1. You can download the software (Testo USB driver) If the installation program does not start automatically:
> Open download folder and start USBDriver.exe.
2. Follow the instructions of the installation wizard.
3. Click on **[Finish]** to complete the software installation

5.2.1.3. P2A software upgrade

1. You can find the P2A software upgrade
2. Download and save P2A software upgrade.
3. Start **P2A upgrade.exe** file.
4. Follow the instructions of the installation wizard.

5.2.2. Starting the software

5.2.2.1. Starting the program

Windows program menu

Windows® 7

- > Click on **[Start] > All Programs > Testo > P2A Software** (double-click on left mouse button).

Windows® 8

- > Click on **[Start]** | right mouse button | **Search** | Enter the name of the application in the search field | **P2A Software**. (double-click on left mouse button).

Windows® 10

- > Click on **[Start] | All Apps | Testo | P2A Software**. (double-click on left mouse button).

5.2.2.2. Establishing a connection with the instrument

Multiple instruments can be attached, however only one connection is active at all times.

- ✓ USB driver is installed (see 5.2.1.2 Installing USB driver).
- 1. Start the P2A software.
- 2. Connect adapter (supplied with the P2A software) to the service interface of the instrument (see 4.5.1 item 2, At a glance).
- 3. Connect instrument/adapter to the PC via the USB interface.
- The instrument file of the attached instrument is shown in the file list.


5.2.2.3. Activating the connection with the instrument

- > Click on the desired instrument file.
- The selected file is marked in colour and the connection with the instrument is activated.

If a connection with the instrument is established when the program is started, the corresponding instrument file is marked automatically.

5.3. Using the software

5.3.1. User interface



1. Menu bar:

Menu	Command	Explanation
File	Open	Shows the Windows dialogue for searching and opening files.
	Save as	Saves the parameters of an instrument or parameter file under a new name.
Edit	Copy	Copies the parameters of the marked instrument or parameter file in the cache.
	Paste	Pastes the parameters from the cache in the marked instrument or parameter file.
View	Toolbar	Activates/deactivates the toolbar or status bar.
	Status bar	

5 Parameterizing, adjusting and analyzing software (P2A software)

Menu	Command	Explanation
?	Check instrument connections	Checks the connections to a connected instrument without the instrument having to be activated.
	Service	A text file with the most important information on the computer and the software is opened via Display service data .
	Information	Shows the version number of the P2A software.

2. Toolbar: Shows the Windows-compliant icons for editing.

3. File:

Icon	File	Explanation
 Symbol shows a transmitter	Instrument file	Instrument file Connection to the instrument has been established. <Type> <Serial number>.cfm File name should not be changed.
 Symbol shows a transmitter with a red minus sign in the upper left corner	Instrument file	Instrument file Connection to the instrument has not been established.
 Symbol shows a transmitter with a white P for parameter file in the upper left corner	Parameter file	<Type> <Serial number> <Date> <Time>.cfp File name can be changed. The name can be selected freely, but it is recommended that you retain the reference to the instrument. Parameter files are always marked red; the parameter values they contain are only forwarded to the instrument after being transmitted to the instrument file.

4. Function buttons: Dialogues on editing and testing the instrument are opened by means of the buttons.

[Change parameterization] see 5.4.2.1 Changing instrument/parameter file

[Test/analyze transmitter] see 5.4.3 Chapter Analyzing/testing the transmitter

[Adjusting the transmitter] see 5.3.4 Chapter Adjusting the transmitter

[Transmitter history] see 5.4.5 Transmitter history

5. File information:

Status	Shown in the window
An instrument file is selected	Type, serial number, firmware version of the instrument.
A parameter file is selected	Type, serial number and firmware version of instrument for which the parameter file was created.
Connection status	Green = connection is active Red = connection is inactive

6. Status bar: Shows the current status when editing via the menu bar.

5.3.2. Editing instrument/parameter file

5.3.2.1. Changing instrument/parameter file

- ✓ The desired instrument/parameter file is marked.

1. Click on **[Change parameterization]**.


- The **Properties of <Instrument type> <Serial number>** dialogue is opened with the **Change parameterization** register.

If the parameters were transmitted from other parameter files into the instrument file, a message is shown with which you can transmit the new parameters to the connected instrument using **[Yes]**.

- > If the parameters should not be transmitted, click on **[No]**.

2. Change or enter parameters in the corresponding fields.

Field	Explanation
Unit/ Analog output	All analog outputs are parameterized in this mask.



Unit/analog output (graphic)	Unit: 0 to 1 V/5 V/10 V or 4 to 20 mA. Vertical: Current version of the analog output (cannot be changed). Horizontal: Min./max. scale end points of selected unit. The curve changes in accordance with the entered value of scale minimum and maximum.
Scale minimum/ maximum	The endpoints of the scaling can be selected up to the stored scale minimum and maximum. In the process, scaling can take place beyond the measuring range in order to adjust the analog output to the customer system, see 4.5.2 Scaling.
Unit	Selection of the physical unit. When changing the unit, standard values are set for scale minimum and maximum.
Signal delay (graphic)	Curve changes according to the set signal delay.

Field	Explanation
Signal delay	Time interval in stages 1 – 15: 1 = no delay 15 = longest delay. The signal delay is added to the reaction time of the sensor. The signal delay shows averaging over the time interval of the selected stage in seconds: Example Stage 10 = average of the readings from the last 10 seconds.

i The delay of the signal in relation to the change in the process is also significantly influenced by the selection of the particle filter.

5.3.2.2. Creating a new instrument file

It is possible to create an instrument file without restarting the P2A software.

- ✓ Transmitter must be connected.
- 1. Click on **File > New connection** in the menu bar.
- Connection to the transmitter is established.

5.3.2.3. Saving parameters

Parameters can be saved in new parameter files.

1. Mark instrument/parameter file.
2. Click on **File > Save as** in the menu bar.
3. Select storage location and enter the file name.
4. Click on **[Save]**.
- The new parameter file is shown in the file list.

Only the parameters are saved from an instrument file; the history data are not adopted.

i The original name (Instrument type, Serial number) is suggested with the current date/time as standard, e.g. "testo 6321 01234578 061120 1403.cfp".

For a standard installation, the files are saved under "C:\Documents and Settings\All Users\Shared Documents\P2A Software". The path can differ depending on the version of the operating system.

5.3.2.4. Opening the parameter file

All parameter files stored in the standard directory path are automatically displayed in the file list when the software is started.

You can also open parameter files that are stored in other directories.

1. Click on **File > Open** in the menu bar.
2. Select the storage location and click on the requisite file.
3. Click on **[Open]**.
 - The selected file is opened. This can be changed and saved (see 5.4.2 Editing instrument/parameter file).

5.3.2.5. Copying and pasting parameters

The parameters of a parameter file can be transmitted to an instrument file or another parameter file from the same instrument type.

1. Select file from which parameters are to be copied.
2. Click on **Edit > Copy** in the menu bar.
3. Select the file which is to be modified.
4. Click on **Edit > Paste** in the menu bar.
 - The parameters are transmitted to the file.



You can also use the common keyboard shortcuts for copying (CTRL+C) and pasting (CTRL+V).

Parameters can also be transmitted using drag & drop, where you drag the icon of the parameter file onto the icon of the target instrument file.

5. Connect and select corresponding instrument.
6. Click on **[Change parameterization]**.
7. Confirm confirmation request.
 - Parameter data are transferred to the instrument.

5.3.2.6. Deleting instrument/parameter file

Instrument/parameter files can be deleted from the file list.

1. Click on the file that is to be deleted with the right mouse button.
2. Select the command **Delete** in the context menu.
 - The instrument or parameter file is deleted from the list.

5.3.3. Analyzing/testing the transmitter

In this section, you can test the outputs of the connected instrument, read off the limit values and reset the parameters to the factory settings.

The function is only available for instrument files.

5.3.3.1. Analyzing/testing the instrument

✓ The required instrument file is marked.

1. Click on **[Test/analyze transmitter]**.
 - The **Properties of <Instrument type> <Serial number>** dialogue is opened with the **Test/analyze transmitter** register.
2. Perform action:

Action	Explanation
Carry out factory reset	Reset the unit, limit value and hysteresis parameters to factory settings (see below).
Test analog output	Test channel 1 (see 5.3.3.3 Testing analog output).
Display min./max. values	Overview of the minimum and maximum values measured since the last reset of the transmitter (see 5.3.3.4 Displaying min./max. values).

3. Click on **[OK]** or **[Cancel]** to close the dialogue.

5.3.3.2. Carrying out factory reset


✓ The required instrument file is marked.

1. Click on **[Test/analyze transmitter]**.
 - The **Properties of <Instrument type> <Serial number>** dialogue is opened with the **Test/analyze transmitter** register.
2. Mark transmitter test.
 - Current operating hours are shown.
3. Confirm control query to perform the reset.
 - The values are reset to the customer-specific factory settings.
4. Click on **[OK]** or **[Cancel]** to close the dialogue.

5.3.3.3. Testing analog output

- ✓ The required instrument file is marked.
- 1. Click on [Test/analyze transmitter].
 - The Properties of <Instrument type> <Serial number> dialogue is opened with the Test/analyze transmitter register.
- 2. Mark channel and test values.

Field/button	Explanation
Transmitter test	Monitoring of analog outputs



Current reading	Readings are updated every second.
Unit	Unit according to the type of analog output.
Default value	Freely definable output value for the respective type of analog output (V or mA), 1 decimal place.

Field/button	Explanation
[Activate]	The entered defined value is forwarded to the analog output by clicking. The current reading is frozen. A warning informs that the value is being transmitted to the connected instrument in the event of existing cabling. Now check the analog output using a precise multimeter.
[Deactivate]	Finish entering the electrical variables at the analog output. The analog output returns to the current reading again.

3. Click on [OK] or [Cancel] to close the dialogue.
- The analog output returns to Measuring Mode again.


5.3.3.4. Displaying min./max. values

The transmitter saves the minimum or maximum value for each channel (measured since the last voltage supply or since the last manual reset).

- ✓ The required instrument file is marked.
1. Click on [Test/analyze transmitter].
 - The **Properties of <Instrument type> <Serial number>** dialogue is opened with the **Test/analyze transmitter** register.
 2. Mark **Min./max. values**.

Field/button	Explanation
Min./max. values	View the min./max. values of each channel. Only the values within the measuring range are shown.

5 Parameterizing, adjusting and analyzing software (P2A software)

Field/button	Explanation
	
Channel	Channel 1 min./max.
Value	Min. or max. value, 1 decimal place.
Unit	Unit selected in Unit/analog output .

3. Reset **Min./max. values**.
4. Click on **[Reset min./max. values]**.
5. Confirm control query to perform the reset.
 - The values are reset to the factory settings.
6. Click on **[OK]** or **[Cancel]** to close the dialogue.

5.3.4. Adjusting the transmitter


This function is used to adjust an attached instrument. The following adjustments may be carried out using the software:

- Analog adjustment (entry via assistant/wizard)
- n-point adjustment (entry via assistant/wizard)


5.3.4.1. n-point adjustment

With an n-point adjustment, the parameters at the 3-6 measurement points are adjusted to the reference value. The reference conditions are obtained by using a precise pressure sensor that should be 5-times more accurate than the transmitter.

- ✓ A precise pressure sensor (5-times more accurate than the transmitter, e.g. DPC precision pressure sensor from testo industrial services) is available.
1. Connect positive output of the pressure sensor (3) to the positive pressure connection of the transmitter (2) and the negative output of the pressure sensor (3) to the negative pressure connection of the transmitter (1).



4. Connect transmitter to PC via service plug.
5. Mark the instrument file of the connected instrument in the P2A software.
6. Click on **[Adjusting the transmitter]**.
 - The **Properties of <Instrument type> <Serial number>** dialogue is opened with the **Adjusting the transmitter** register.
7. Mark **n-point adjustment**.
8. Click on **[Start wizard ...]** and follow the instructions of the wizard.
 - The adjustment is performed when the wizard is closed.

Field	Explanation
	

How much pressure is actually applied	Required field: Entry of the value read off at the pressure sensor.
---------------------------------------	---

i The n-point adjustment must always be carried out to its full extent and in good time at all selected adjustment points.


9. Disconnect connections between the pressure sensor and the pressure connections of the testo 6321.

5.3.4.2. Adjusting the analog output

- 1. Connect precision multimeter (see 4.6.2 Wiring the instrument).
- 2. Mark the instrument file of the connected instrument.
- 3. Click on **[Adjusting the transmitter]**.
- The **Properties of <Instrument type> <Serial number>** dialogue is opened with the **Adjusting the transmitter** register.

5 Parameterizing, adjusting and analyzing software (P2A software)

4. Click on **[Start wizard ...]** and follow the instructions of the wizard.
- The adjustment is performed when the wizard is closed.

Field	Explanation
	
Default value	The analog output value from the last performed adjustment is given at the output. Value of the factory adjustment: • Lower adjustment point: approx. 10 % of the max. value • Centre adjustment point: approx. 50 % of the max. value • Upper adjustment point: approx. 90 % of the max. value
Measured analog value	Required field: Entry of the value read off at the multimeter.


5.3.5. Transmitter history


Parameterizations and adjustment processes are registered in the transmitter with an operating hours stamp.

In the history overviews (explained later in more detail), past processes and events can be made visible.

i For entries that are performed using the P2A software, the name of the user logged into Windows appears in the User field, while the date/time and operating hour are shown in the Date/time field.

- 1. Mark the instrument file of the connected instrument.
- 2. Click on the **[Transmitter history]** button.
 - The **Properties of <Instrument type> <Serial number>** dialogue is opened with the **Transmitter history** register.
- 3. Click on the required entry in the list to change the display.

Field	Explanation
	
Operating hours / date/time	Operating hour/time stamp at which the change at the instrument was performed.
User	Name with which the user is logged into the operating system.
Comments	Type of parameter change, e.g. "Unit of channel 1 from Pa to hPa".

Field	Explanation
	

Selection of adjustment histories: **n-point adjustments / Analog adjustments**.

Operating hours / date/time	Operating hour/time stamp at which the change at the instrument was performed.
User	Name with which the user is logged into the operating system.
Channel	Analog adjustment: Channel 1.
Specification	Analog adjustment: Current reading.
Multimeter	Analog adjustment: Value read off at reference instrument.
Offset	Analog adjustment: Deviation at time of adjustment.
Pressure specification	n-point adjustment: Value read off at pressure sensor.
Unit	Unit during the adjustment.

> To print out the history data, click on **[Print]**.

i The printing job is automatically sent to the default printer for the operating system.
With **[Set up printer ...]** a different printer can be selected or the printout can be edited.

4. Click on **[OK]** or **[Cancel]** to close the dialogue.

6 Tips and assistance

6.1. Questions and answers

Question	Possible causes/solution
Connection to instrument cannot be established	Check connection cable/plug contacts
Malfunction (with and without display)	Analysis using the P2A software, see 5.3.3 Analyzing/testing the transmitter
Adjustment is to be reversed	Carry out factory reset (Test/analyze transmitter).
When does a stable current reading appear?	After approx. 20 seconds

If we could not answer your question, please contact your dealer or Customer Service.

6.2. Accessories and spare parts

Description	Article no.
Interface and software	
P2A software (parameterizing, adjusting, analyzing) incl. USB adapter	0554 6020
Supply	
Mains unit (desktop, wall-mounted)	0554 1748
Mains unit (top-hat rail mounting)	0554 1749
Calibration	
Standard ISO calibration certificate, transmitter only	0520 1000
Standard DAkkS calibration certificate, transmitter only	0520 1200

For a complete list of all accessories and spare parts, please refer to the product catalogues and brochures

6.2.1. Ordering options for testo 6321 transmitter (0555 6321)

Order code	Characteristic
Axx Measuring range	
A03	0 to 100 Pa
A05	0 to 10 hPa
A06	0 to 20 hPa
A07	0 to 50 hPa
A08	0 to 100 hPa
A09	0 to 500 hPa
A10	0 to 1000 hPa
A11	0 to 2000 hPa
A23	-100 to 100 Pa
A25	-10 to 10 hPa
A26	-20 to 20 hPa
A27	-50 to 50 hPa
A28	-100 to 100 hPa
A29	-500 to 500 hPa
A30	-1000 to 1000 hPa
A31	-2000 to 2000 hPa
Bxx Analog output/supply	
B02	0 to 1 V (4-wire, 24 V AC/DC)
B03	0 to 5 V (4-wire, 24 V AC/DC)
B04	0 to 10 V (4-wire, 24 V AC/DC)
B06	4 to 20 mA (4-wire, 24 V AC/DC)
Cxx Display	
C00	Without display
C01	With display
Exx Housing colour and logo	
E01	Grey housing, testo logo in colour

Order code	Characteristic
E02	White housing, without testo logo
E03	White housing, black-and-white testo logo
Fxx Differential pressure unit	
F01	Pa/Min/Max
F02	hPa/Min/Max
F03	kPa/Min/Max
F04	mbar/Min/Max
F05	bar/Min/Max
F06	mm H ₂ O /Min/Max
F07	inch H ₂ O /Min/Max
F08	inch HG /Min/Max
F09	kg/cm ² /Min/Max
F10	PSI/Min/Max