



testo 6740

Instruction manual

en



# Preface

## Preface

Dear Testo Customer

Congratulations for choosing a Testo product. We hope that you will enjoy many years of using the product and that it will help you in your work.

If problems should occur which you cannot rectify yourself, please consult our service department or your dealer. We will endeavour to provide fast and competent assistance to save you long periods out of operation.

## General information

This Instruction manual contains important information about the features and use of the product. Please read this document through carefully and familiarise yourself with the operation of the product before putting it to use. Keep the Instruction manual to hand so that you can refer to it when necessary.

### Pictograms

This product could be dangerous if operated incorrectly. Information that requires particular attention is identified in this Instruction manual by pictograms:

Warnings are identified by means of a warning triangle. The relevant signal word! indicates the degree of risk:



Signal word!

**Warning!** means: Serious physical injury could occur if you do not take the precautionary measures indicated.

**Caution!** means: Slight physical injury or material damage could occur if you do not take the precautionary measures indicated.

**Pay particular attention to warnings and take the precautionary measures indicated in order to avoid danger.**

**!** Notes on special cases and peculiarities in the handling of the product are indicated by an exclamation mark.

### Standards/Approvals

According to the conformity certificate, this product fulfills all 2014/30/EU guidelines.

# Contents

Preface .....	3
General information .....	4
Contents .....	5
1. Basic safety information .....	6
2. Intended use .....	7
3. Product description .....	8
3.1 System components.....	8
3.2 Operating elements .....	8
3.3 Settings .....	9
3.4 Current output intervals.....	9
4. Initial operation .....	10
4.1 Mechanical assembly .....	10
4.2 Electric connection .....	12
4.3 Analog output / Limit signal outputs .....	14
5. Menu guide (0555.6743 / 0555.6744 only) .....	16
6. Adjustment on site .....	18
7. Care and maintenance .....	19
8. Troubleshooting.....	20
9. Technical data .....	21
9.1 Measurement ranges and accuracies .....	21
9.2 Additional instrument data .....	21
9.3 Uncertainty pressure dewpoint temperature .....	22
10. Accessories / Spare parts .....	23

# 1. Basic safety information



## **Avoid electrical hazards:**

- ▶ Never take measurements with the instrument and its probes on or near live components unless the instrument is expressly approved for current and voltage measurements.



## **Protect the instrument:**

- ▶ Never store the unit together with solvents (e.g. acetone).



## **Preserving product safety/warranty entitlement:**

- ▶ Operate the instrument only within the parameters specified in the Technical data.
- ▶ Handle the instrument appropriately and according to its intended purpose.
- ▶ Never apply force!
- ▶ Temperature data on sensors/probes refer only to the measurement range of the sensors. Do not subject handles and lines to temperatures greater than 70°C if they are not expressly approved for higher temperatures.
- ▶ Open the instrument for maintenance and repair purposes only if specifically described in the Instruction Manual.
- ▶ Maintenance work should only be carried out if described in the Instruction Manual. Please adhere to the steps described. For safety reasons, please only use spare parts from Testo.

Any additional work should only be carried out by authorised trained personnel. Otherwise Testo does not accept responsibility for the functioning of the instrument following maintenance and for the validity of approvals.



## **Dispose of carefully:**

- ▶ Once its service life has come to an end, return the instrument to us and we will dispose of it.

## 2. Intended use

**The instrument is intended for use in the following applications:**

The testo 6740 instrument is a pressure dew point transmitter for measuring trace humidity. It is used in the following areas:

- Monitoring trace humidity in compressed air systems
- Controlling and monitoring (compressed air) driers.
- Monitoring humidity and temperature in medical compressed air or granulate driers.




Application in hazardous areas is not allowed!

---

## 3. Product description

### 3.1 System components



### 3.2 Operating elements

The instruments with the article numbers 0555.6741 and 0555.6742 do not have any additional operating elements.

The instruments with the article numbers 0555.6743 and 0555.6744 have a keypad and a display to input and read off settings (See 5. Menu guide, p. 15).

## 3.3 Settings


The parameters in the instrument are assigned the following values in the factory (default values):

Parameter	Pressure dew point <sup>1</sup>		Atmospheric dew point <sup>1</sup>		Relative humidity	Temperature		Absolute humidity	
Unit	°Ctp	°Ftp	°CtA	°FtA	%rF, %rh, %Hr	°C	°F	ppm <sub>v</sub>	mg/m <sup>3</sup> (Abs)
4mA	-60	-75	-60	-75	0	0	32	0	0
20mA	30	85	30	85	100	50	120	30000 <sup>2</sup>	30000 <sup>2</sup>
LS	4	40	4	40	30	10	50	8400	7000
US	12	55	12	55	50	30	85	13000	9600
Hyst	2	2	2	2	2	2	2	20	20

<sup>1</sup> With dew point temperatures <0°Ctp / <0°CtA / <32°Ftp / <32°FtA the frostpoint temperature (dewpoint upon ice) is displayed

<sup>2</sup> Display is shown to the power of ten: 30E3 (corresponds to  $30 \times 10^3 = 30 \times 1000 = 30000$ )


## 3.4 Current output intervals





## 4. Initial operation

### 4.1 Mechanical assembly



We recommend you wrap the thread of the process connection in sealing tape (e.g. PTFE) or place it in a copper gasket (inner diameter: 21mm).

- Force should only be applied to the Allen screw 1.

There are 3 different options for assembly depending on the application:

#### Without measurement chamber and cooling coil

Assembly	Application
Without measurement chamber and cooling coil	<ul style="list-style-type: none"> <li>- Process temperatures 0 to 50°C</li> <li>- It is possible to attach sensor directly in process</li> <li>- No quick assembly/dismantling of testo 6740 required and flow on sensor is sufficient (1l/min)</li> </ul>
With measurement chamber	<ul style="list-style-type: none"> <li>- Process temperatures 0 to 50°C</li> <li>- Fast assembly/dismantling of testo 6740 required and/or flow on sensor is insufficient (1l/min)</li> </ul>
With measurement chamber and cooling coil	<ul style="list-style-type: none"> <li>- Process temperatures 50 to 200°C</li> </ul>



#### Warning

Compressed air!


Risk of injury!

- Depressurise pipe sections (e.g. compressor off or use bypass) and aerate before opening.

- 1 Screw process connection (G $\frac{1}{2}$  or NPT $\frac{1}{2}$ " ) into the matching thread.

The housing can be rotated by 350°. Do not use force when aligning.

- 2 Set up housing so that the display can be easily read. Tighten grub screw 1.
- 3 Complete aeration of pipe section and apply pressure to pipe section.




**With measurement chamber (max. 15bar)**

- 1 Check the measuring chamber for soiling and, if necessary, blow it out before use.
- 2 Screw in process connection (G $\frac{1}{2}$ ) of the testo 6741 / 6743 transmitter in measurement chamber thread.
- 3 Snap push-in quick connection of measurement chamber in standard socket of compressed air line.

**With measurement chamber and cooling coil (max. 15bar)**

- 1 Check the measuring chamber and cooling section for soiling and blow out if necessary before use. Maschinelle Übersetzung
- 2 Screw in process connection (G $\frac{1}{2}$ ) of testo 6741 / 6743 transmitter into thread of measurement chamber.
- 3 Snap push-in quick connection of measurement chamber in push-in quick connection of the cooling coil.
- 4 Snap second push-in quick connection of the cooling coil into the standard socket of the compressed air line.

## 4.2 Electric connection



### Standard plug

We recommend using a 2-core cable with a tight braided shield and a wire cross-section of 0.2 to 0.5 mm<sup>2</sup>, such as the enclosed snap ferrite 0204 0201 at a distance of 5 cm from the device plug around the cable (for cable cross-section 4.5 - 6.0 mm).

- 1 Loosen and remove (1) screw at the back of the plug and remove plug from transmitter (2).
- 2 Remove plug socket from the plug housing. To do this apply a small screwdriver to the point marked with "lift" and press out carefully (3).
- 3 Screw on the cable positioning device (4) and guide the cables through the plug housing (5).
- 4 Connect cable ends to the screw terminals of the plug socket (6):

#### Plug socket terminals

1: + (4 to 20mA), power: 12...30VDC

2: - (4 to 20mA)


3: Not assigned

4: Measuring earth (cable screen)


- 5 Insert plug socket into plug housing again until it snaps into place (7) and screw on cable fixing unit.
- 6 Attach plug to transmitter (8) and secure with screw (9)

### 0554.3302 plug (with 2 switch outputs)

We recommend an 8 wire cable with a tightly braided screen, wire cross-section 0.2 to 0.8mm<sup>2</sup>.



- 1 Loosen and remove screw (1) at the back of the plug and remove plug from transmitter (2).
- 2 Tilt the cover of the plug housing at an angle and remove (3).
- 3 Remove plug socket from the front and the relay board from the back out of the plug housing.
- 4 Screw on cable positioning device (4) and guide cables through the plug housing.
- 5 Connect cable ends to the screw terminals of the relay board or the plug socket (5):




The supply lines need to be galvanically connected, so connect either (A) - (A) or (B) - (B)!

Plug socket terminals	
1: I + (4 to 20mA)	(A)
2: I - (4 to 20mA)	
3: (connected to relay board in factory)	(B)
⏏ Put on screen	

Current signal and supply 20 to 28 VDC

Relay board terminals	
1: 20 to 28 VDC	(A)
2: LS +	
3: LS -	
4: US +	
5: US -	
6: 0 VDC	(B)

- 
- 6

Push plug socket and plug board into the plug housing (pay attention to alignment) and close lid.
- 7


Screw on cable positioning device.
- 8

Attach plug to transmitter (6) and screw into place (7).

4.3 Analog output /  
Limit signal outputs


Standard plug/ 0554.3302 plug

Both plug variations have a 4 to 20mA analog output available in two-wire technology.



### Limit signal outputs with 0554.3302 plug

Two floating contacts (NO contact) are available.



Default settings for other parameters (ppm, %RH, ...) See 3.3 Settings, p.8


Example:


- The lower alarm shall be switched at +8 °C td
- The higher alarm shall be switched at +12 °C td

Set these values

- LS = 6 °C td
- US = 10 °C td
- Hyst = 2 °C td
- Switching point lower alarm = LS + Hyst = 8 °C td
- Switching point upper alarm = US + Hyst = 12 °C td

## 5. Menu guide (0555.6743 / 0555.6744 only)



**Notes:**

- <sup>1</sup> If there are breaks in the input, the system returns automatically to the display mode after approx. 1min.
- <sup>2</sup> In the case of the units ppm and Abs (mg/m<sup>3</sup>), values are displayed/entered to the power of ten. Examples: 15E1 corresponds to 15 x 10 = 150, 02E2 corresponds to 2 x 100 = 200, 21E3 corresponds to 21 x 1000 = 21000
- <sup>3</sup> Keep button pressed (1s / 3s / 5s / 10s, corresponding to setting in (1), default setting: 5s).
- <sup>4</sup> Only with deactivated code (can be set in Prog - UCode menu).
- <sup>5</sup> Absolute pressure (can be set in Prog - Pres menu) is included in the calculation of the ppm value and atmospheric dew point (°Ctd / °Ftd).
- <sup>6</sup> For negative values: select "-" at left digit position.
- <sup>7</sup> To deactivate codes: Enter 0000. Important: Note down the code at a suitable point, operation is impossible without a valid code.
- <sup>8</sup> Can only be used together with the 0554.3302 plug.
- <sup>9</sup> Menu is only available if one of the following units is set: °Ctd, °Ftd, %rF, %Hr or %rh (can be set in Unit menu). Also see 6. Adjustment on site, p. 18.
- <sup>10</sup> The displayed reading flashes if the scaling limits are exceeded (can be set in Menu UNIT - S-Lo or S-Hi).
- <sup>11</sup> Compare chapter 6.
- <sup>12</sup> Display blinks if actual values are below 4mA setting or above 20mA setting.



## 6. Adjustment on site

### One point adjustment by inputting one reference value

Using one point adjustment, you can enter a reference value for a working point (e.g.  $-40^{\circ}\text{C td}$ ) specified by you. In this way you will achieve a minimum target/actual deviation from this working point.

A dew point mirror is ideal as a reference measuring instrument.

**!** The Adj menu in which the reference value is entered is only available if one of the following units is set:  $^{\circ}\text{Ctd}$ ,  $^{\circ}\text{Ftd}$ , %rF, %Hr or %rh (See 5. Menu guide, p. 16, Unit menu, Setting unit).

### Reference value input

Optimum precision is achieved at reference value  $-40^{\circ}\text{C td}$ . In case low dewpoints ( $<-25^{\circ}\text{C td}$ ) are relevant, it is suggested to avoid reference values  $>-30^{\circ}\text{C td}$  (else loss of precision).

- 1 Expose reference measuring instrument and testo 6740 to identical, constant conditions and await adjustment time.
- 2 Measure reference value and compare with testo 6740 reading.
- 3 If there are deviations in the values, enter reference value in Adj menu.

## 7. Care and Maintenance

### Filter, measurement chamber, cooling coil

If process conditions are oily or dusty, the stainless steel sintered filter should be cleaned and also the measurement chamber and cooling coil should be cleaned if used.

- ▶ Unscrew/remove filter, measurement chamber and cooling coil, purge with compressed air or place in an ultrasonic bath.

### Sensor cleaning

During cleaning, avoid touching the sensor at all costs.

Do not clean the sensor mechanically, as this can damage the cover electrode.

- ▶ Screw off filter cover.
- ▶ Carefully rinse the sensor with isopropyl alcohol and/or distilled water.
- ▶ Allow the sensor to dry completely

!

!

## 8. Troubleshooting

Fault	Possible causes	Remedy
Analog output values too low/too high	- Incorrect scaling or unit	► Change scaling or unit in Unit menu
No signal	- Connection interrupted or - Supply voltage too low - Polarity incorrect	► Check cables  ► Check power: Standard plug min. 12VDC 0554.3302 plug: min. 20VDC
Signal >21mA	- Sensor defect (broken).	Sensor must be replaced. ► Contact your local distributor or Testo's Customer Service.
Signal <4mA	- Sensor corroded	Sensor must be replaced. ► Contact your local distributor or Testo's Customer Service.
Display oF	- No signal from sensor	► Contact your local distributor or Testo's Customer Service.
Displayed reading flashes	- Scaling limits exceeded	► Change scaling limits in Unit - S-Lo or S-Hi Menu

If the fault cannot be repaired by following the suggestions given in the above table, please contact your local distributor or Testo's Customer service department.

## 9. Technical data


### 9.1 Measurement ranges and accuracies

Type of measurement	Measurement range	Accuracy
Pressure dew point temperature (trace humidity)	-45 to +30 °Ctd	±1 K at ±0 °Ctd ±3 K at -20 °Ctd ±4 K at -40 °Ctd (at 25 °C)
atm. dew point	-70 to -15 °C td at 30 bar <sub>rel</sub> -54 to +10 °C td at 3 bar <sub>rel</sub> -45 to +30 °C td at 0 bar <sub>rel</sub>	cf. pressure dew point temperature
Temperature	±0 to +50°C	±0.5 K

### 9.2 Additional instrument data

Characteristic	Values
Supply voltage	24 VDC (standard plug: 12 to 30 VDC allowed, 0554.3302 plug: 20 to 28VDC allowed)
Max. load	12 V: max. 100 Ohm, 24 V: 650 Ohm, 30 V: 950 Ohm
Ambient temperature	-20 to +70 °C (process temperature 0 to +50 °C)
Storage/transport temperature	-40 to +80 °C
Protection class IP 65	(with plug attached and cable connected)
Rotatability (display alignment)	350°
Humidity sensor	Testo humidity sensor with logged trace humidity-adjustment at -40 °Ctp / 6 bar
Temperature sensor	NTC
Sensor protection	Stainless steel sintered cap
Pressure resistance	-1 bar <sub>rel</sub> to +50 bar <sub>abs</sub> Measurement chamber 0554.3303: max. 15bar <sub>abs</sub>
Dimensions	199.5 x 37 x 37 (with standard plug), 203.5 x 37 x 37 (with 0554.3302 plug)
Warranty	2 years
Analog output	
Signal	4 to 20mA, two-wire technology
Scaling	Standard: 4 to 20 mA = -60 to +30 °Ctd, with freely scalable display
Output parameters	°Ctp, °Ftp, °CtA, °FtA, %RH, ppm <sub>v</sub> , mg/m <sup>3</sup> , °C, °F
Resolution	12 bit
Accuracy	±40µA
Limit value outputs (optional, only with 0554.3302 plug)	
Contacts	2 NO contacts, potential-free, max. circuit 30 V / 0.5 A
Lower switching point (LS + HYST)	+6°Ctd, with display freely programmable
Upper switching point (US + HYST)	+12°Ctd, with display freely programmable

## 9.3 Uncertainty pressure dewpoint temperature



## 10. Accessories / Spare parts

Name	Part no.
Basic instruments (incl. plug for access line)	
with process connection G1/2, without display	0555 6741
with process connection NPT1/2", without display	0555 6742
with process connection G1/2, with display	0555 6743
with process connection NPT1/2", with display	0555 6744
Accessories	
Cable connection plug for power/analog output 4 to 20 mA, with 2 floating switch contacts and 2 LEDs (limit signal output, alarm output)	0554 3302
Measurement chamber for optimum flow on humidity sensor, max. 15 bar, for thread G½	0554 3303
Cooling coil for process temperatures above 50 °C (up to 200 °C)	0554 3304
ISO calibration certificate for pressure dew point (-40° to 0° Ctp at 6 bar), free choice of points	0520 0116
ISO calibration certificate for pressure dew point at -10° Ctp and -40° Ctp	0520 0136
Power unit (desk-top unit), 100 to 240VAC / 24VDC (350 mA)	0554 1748
Power unit (DIN rail mounting), 100 to 240VAC / 24VDC (2,5 A)	0554 1749